

Stowe

Installation Guide


Contact Technical Support Team

✉ support@purelinkav.com


☎ (201) 488-3232 Ext.2992

What's included


A iCON-T10 Touch Screen Controller




B iCON-E1 Control Port Expander




D 16 Port PoE Network Switch




D-PS 16 Port PoE Network Switch Power Supply



F VIP-CAM-30-20x Pro PTZ Camera with HDMI, USB 2.0, and LAN Output




F-PS VIP-CAM-30-20x (Powered PoE) Power Supply (Optional)




What's included


G RoomView-110W
Room Scheduling Panel with Dash




G-W RoomView-110W
Wallmount




G-PS RoomView-110W
Power Supply (When using WiFi)




K PS-610 4K60 Seamless Presentation Switcher with Dante




K-RX PS-610 Rx




K-PS PS-610 Power Supply




L USB-C Power Injector




L-PS USB-C Power Injector
Power Supply




M DIO-AMP150 Dante ISO Amplifier with DSP




M-PS DIO-AMP150 Power Supply




What's included




HDMI ↔ HDMI 3M




CAT ↔ CAT 10M




USB-C ↔ HDMI 3M




USB-C ↔ USB-C 3M




USB-A ↔ USB-B 3M



Mini Phoenix RS-232 15M




Mini Phoenix ↔ 3.5mm female 7.6M




3.5mm ↔ IR Blaster 10M

1




2



*CFE: Customer Furnished Equipment


OR



Display Control Option 2




OR

Display Control Option 3









5




6







8




9




10




11



12




13




14


Network Connection Option 1 - PoE




Network Connection Option 2 - WiFi



15



16



 **NEXT STEP**


Stowe Operation Guide

Scan here to access the guide.



Contact Technical Support Team

 support@purelinkav.com

 (201) 488-3232 Ext.2992